

Command	Action
H	Help
STA	Show Global System Status
SET RST	Reset to Factory Defaults
SET RBT	System Reset to Reboot
SET ADDR xx	Set System Address to xx (xx = 01–99)
GET ADDR	Get System Address
GET TMDS CHECK	Check whether the TMDS data cable works properly
GET CRC VAL	Get CRC value
SET INx EDID y	Set Input x EDID index (x = 0–1, 0 = ALL; y = 0–3: 0 = 1080P_2CH, 1 = 4K60Hz_2CH, 2 = 8K60Hz_2CH, 3 = User_EDID)
SET INx EDID Uy DATAz	Write EDID data to User y buffer of Input x (x = 0–1, 0 = ALL; y = 1; z = EDID data)
GET INx SIG STA	Get Input x signal status (x = 0–1, 0 = ALL)
GET INx EDID	Get Input x EDID index (x = 0–1, 0 = ALL)
GET INx EDID y DATA	Get Input x EDID y data (x = 0–1, 0 = ALL; y = 0–3)
GET INx VID INF	Get Input x video information