



162-inch tripod installation diagram-ST90


Screen front installation diagram



Screen side installation diagram




Installation diagram on the back of the screen




Wall mounting strip installation location reference
--Ensure the center-mounted installation effect of the whole machine

Screen installation diagram



Wall hanging strip assembly diagram



*The third-generation all-in-one hemming machine has been assembled and shipped, and no assembly is required on site.
--Installation instructions will be updated after the camera and touch radar solutions are finalized

- installation steps:
1. Install the tripod;
 2. Assemble the wall hanging strip assembly according to the diagram and reference instructions;
 3. Hang the entire screen on the tripod;
 4. The tripod structure shown in the figure refers to ST90.

MODEL NO.	Tripod installation diagram	UNIT	mm
PART NO.		SCALE	1:1
PART NAME		REV.	
MATERTAL		SHEET	
SURFACE		CHK'D	
COLOR NO.		FIRST ANGLE PROJECTION	
DRAWN			